

manual

Jogging belt

Item: 64462

EN

NO

SV

Specifications/specifikasjoner/specifikationer

Batteries/batterier: 1x CR2032 (included)

Length/lengde/längd: 80 - 100 cm

Size/mål/storlek: 1000x25 mm

Weight/vekt/vikt: 64 g

www.luxorparts.com

Box 50435 Malmö

Sweden

2023-05-17



Luxorparts®

ENGLISH

Use

Pull out the transparent plastic tab to activate the batteries. Turn the light on by pressing the button. Press it again to turn it off. The length of the belt can be adjusted from 80 cm to 100 cm. The batteries last up to 49 hours.

Safety information

The product is not a toy, keep away from children.

NORSK

Bruk

Fjern den gjennomsiktige plastfliken for å aktivere batteriene. Trykk på knappen for å slå på lyset. Trykk en gang til for å slå av. Du kan justere lengden på beltet fra 80 til 100 cm. Batteriene varer i ca. 49 timer.

Sikkerhetsinformasjon

Produktet er ikke et leketøy. Det skal holdes utenfor barns rekkevidde.

SVENSKA

Användning

Dra ut den genomskinliga plastfliken för att aktivera batterierna. Sätt igång ljuset genom att trycka på knappen. Tryck på den igen för att släcka av ljuset. Du kan justera längden på bältet till mellan 80 cm och 100 cm. Batterierna varar upp till 49 timmar.

Säkerhetsinformation

Produkten är ingen leksak, håll den utom räckhåll för barn.