

manual

Remote control

Item: 66280-66284

EN

NO

SV

Luxorparts®

www.luxorparts.com
Box 50435 Malmö
Sweden
2017-02-07



ENGLISH

Use

Insert two batteries. Do not mix old and new or different types of batteries. If the remote control responds poorly or the range is short, replace the batteries.

Batteries are to be kept away from heat, sunlight and fire. Replace an empty battery with a battery of the same or corresponding type only. Return used batteries to your local battery recycling. Always keep batteries away and out of reach from children!

NORSK

Bruk

Sett i to batterer. Ikke bland gamle og nye eller forskjellige typer batterier. Skift batterier hvis fjernkontrollen reagerer dårlig eller hvis rekkevidden er for kort.

Batteriene skal ikke utsettes for varme, sollys eller flammer. Et utladet batteri skal bare skiftes ut med et batteri av samme eller tilsvarende type. Brukte batterier skal leveres til miljøstasjoner eller batteriforhandlere. Batterier skal oppbevares utilgjengelig for barn!

SVENSKA

Användning

Sätt i två batterier. Blanda inte gamla och nya eller olika typer av batterier. Om fjärrkontrollen reagerar dåligt eller om räckvidden är kort, byt batterier.

Batterier ska hållas borta från värme, solljus och eld. Ersätt endast förbrukat batteri mot batteri av samma eller motsvarande typ. Förbrukade batterier skall lämnas till din lokala batteriinsamling. Förvara alltid batterier utom räckhåll för barn!