

manual

Portable fan

Item: 99580

EN

NO

SV

www.rubicson.com
Box 50435
Malmö, Sweden
2023-10-12



Rubicson®

Specifications

Battery:	Li-ion 18650 3.7 V, 2000 mAh
Charging:	5 V/1 A (USB-C cable included)
Charging time:	3.5 hours
Battery time:	2.5–9 hours
Size:	105x38x215 mm

Package content

- Fan
- Manual
- USB-C to USB-C cable (0,8 m)

Charging

Connect the included USB-C cable to a USB-C charger (not included). Connect the other end to the fan. The LED indicator lights up green when the fan is fully charged and blue when the fan is in use. A full charge takes up to 3.5 hours.

Use

Press the button to turn on the fan. Press the button repeatedly to alternate between the three different speed settings. Press the button again (after setting 3) or press and hold it for 3 seconds to turn the fan off.

You can change the angle of the fan by manually bending it backwards. There is a table stand beneath the top that can be folded out. The front cover of the fan is detachable if you need to clean the fan blades.

Safety information

The product contains a rechargeable Li-ion battery that cannot be replaced. Dispose of batteries according to the requirements of the country where they are disposed. Avoid touching the rotating fan blades as they're sharp. Clean the fan by gently scrubbing it with a moist cloth.

Spesifikasjoner

Batteri:	Li-jon 18650 3,7 V, 2000 mAh
Lading:	5 V/1 A (USB-C-kabel følger med)
Ladetid:	3,5 timer
Batteritid:	2,5–9 timer
Mål:	105x38x215 mm

Pakkens innhold

- Vifte
- Manual
- USB-C til USB-C-kabel (0,8 m)

Lading

Koble den medfølgende USB-C-kabelen til en USB-C-lader (følger ikke med). Koble den andre enden til viften. LED-indikatoren lyser grønt når viften er fulladet og blått under bruk. Det tar 3,5 timer å lade batteriet helt opp.

Bruk

Klikk på knappen for å starte viften. Fortsett å trykke på knappen for å bytte mellom de tre ulike hastighetsinnstillingene. Trykk på knappen en gang till eller hold in knappen i 3 sekunder for å slå av viften. Du kan også endre vinkelen på viften ved å bøye den bakover. Det er også et lite stativ som kan foldes opp. Frontgitteret kan tas av hvis du vil rengjøre viftebladene.

Sikkerhetsinformasjon

Produktet inneholder et oppladbart Li-ion-batteri som ikke kan skiftes ut. Unngå å berøre de roterende viftebladene da de er skarpe. Rengjør viften forsiktig med en fuktig klut. Apparatet skal avhendes på miljøstasjon.

Specifikationer

Batteri:	Li-jon 18650 3,7 V, 2 000 mAh
Laddning:	5 V/1 A (USB-C-kabel medföljer)
Laddningstid:	3,5 timmar
Batteritid:	2,5–9 timmar
Mått:	105x38x215 mm

Förpackningens innehåll

- Fläkt
- Manual
- USB-C till USB-C-kabel (0,8 m)

Laddning

Anslut den medföljande USB-C-kabeln till en USB-C-laddare (medföljer ej) och ett vägguttag. Anslut den andra änden till fläkten. LED-indikatorn tänds och lyser grönt när fläkten är fulladdad och blått när den används. Det tar 3,5 timmar för att ladda batteriet fullt.

Användning

Tryck på knappen för att starta fläkten. Tryck på knappen upprepade gånger för att byta mellan de tre olika hastighetsinställningarna. Tryck på knappen ytterligare en gång (efter tredje hastighetsinställningen) eller håll in knappen i 3 sekunder för att stänga av fläkten.

Du kan ändra vinkeln på fläkten genom att böja den bakåt. Det finns ett bordsställ som kan fällas ut under toppen på fläkten. Framre skyddsgallret är avtagbart om du behöver rengöra fläktbladen.

Säkerhetsinformation

Produkten innehåller ett uppladdningsbart Li-jon batteri som inte kan bytas ut. Återvinn apparaten enligt lokala bestämmelser. Undvik att röra de roterande fläktbladen då de är vassa. Rengör fläkten genom att försiktigt skrubba den med en fuktig trasa.