

manual

Laptop charger

Item: 44494

EN

NO

SV

Specifications

Input: 100-240 V, 50/60 Hz

Output: 19.5V, 4.62 A, 90 W

Plug: 4.5x3.0 mm

Power cable length: 80 cm

Adapter cable length: 175 cm

www.kjell.com
Box 50435 Malmö
Sweden
2017-09-21



ENGLISH

Only intended for household use and may only be used indoors. Never use in damp areas or near a sink, wash stand, bathtub, shower, etc. Never touch with wet hands.

The mains plug is used as the disconnect device, therefore the mains plug shall remain readily operable.

The product is not suitable for use in places where children are likely to be present.

Do not disassemble or remodel the product in any way.

NORSK

Kun ment for husholdningsbruk, og skal kun brukes innendørs. Bruk aldri i fuktige rom eller i nærheten av kjøkkenbenk, servant, badekar, dusj, osv. Du må aldri berøre apparatet med våte hender. Strømadapteren brukes som strømbryter, derfor skal strømadapteren alltid være enkel å nå og håndtere.

Produktet er ikke beregnet til bruk på steder der barn kan være.

Ikke demonter eller endre produktet på noen måte.

SVENSKA

Endast avsedd för hushållsbruk och får bara användas inomhus. Använd aldrig i fuktiga utrymmen eller i närheten av diskho, tvättställ, badkar, dusch, etc. Vidrör aldrig med våta händer. Nätkontakten används som strömbrytare, därav ska nätkontakten alltid vara enkel att nå och hantera.

Produkten är inte avsedd att användas på platser där barn kan vistas.

Montera inte isär eller ändra om produkten på något vis.